


## DRAIN CLEANER

### Operating manuals and Safety Instructions

The drain cleaner 5m is intended for unclogging drain pipes (after the siphon) under washbasins and sinks.

The drain cleaner is ideal for unclogging

U and S bends. The drain cleaner has a 5 meter spring coil with an auger (drill bit).



#### Caution!

Improper handling can injure the user or damage the device. Read the safety instructions first!

## SAFETY INSTRUCTIONS



#### Safety for user

- Wear rubber gloves when using a chemical cleaner.

#### Check before use


- Device visually on defects.

**Contact your rental company should you encounter any problems with the device!**

#### Safety during use

- Keep the workplace clean. Dirt from drain pipes can make floors slippery.


## 1. OPERATING FUNCTIONS



A Nut  
B Coil  
C Drum

D Auger  
E Handle


## 2. PREPARATION FOR USE



**Caution!** Remove the siphon and thoroughly clean it!

- Loosen **A**
  - Pull out **B** approx. 30 cm from **C**
- Caution!** Do not feed the coil through ceramic sanitary. First remove the ceramic sanitary, avoid damage!

## 3. OPERATING DRAIN CLEANER



- Slide **D** with **B** in the drain until you reach the blockage
  - Tighten **A**
- Caution!** Tightening **A** prevents jamming and bending **B** in **C**!
- Turn **E** to clear blockage
  - Loosen **A** and slide **D** with **B** further in the drain
- Caution!** Repeat steps 2, 3 and 4 until the drainpipe has been completely cleared!
- Remove **D** with **B** from the drain pipe and push **B** in drum **C**
- Caution!** Should **B** jam: loose **A** turn **E** and tighten **A** again when **B** has got unstuck!
- Caution!** Rinse drain pipe thoroughly and check that water runs freely!

## 4. AFTER USE

- Clean the device